

VI.5.3D-TABLES PROGRAM FCST HCL TECHNIQUE TABLES

Purpose

Technique TABLES sets whether tabular output is to be printed by Operations.

Valid values are NO (0), YES (1) and criteria (2).

The Global default is criteria (2).

This Technique is Nonuniversal.

Form of Input

TABLES(integer)

where integer is 0, 1 or 2 specifying whether to:

0 = do not print

1 = print

2 = use criteria in the Operations to determine whether or not to print

Example

TABLES(0)

Tabular output will not be printed.

TABLES(2)

Tabular output will be printed based on Operation criteria.

TABLES (F SPRING)

Tabular output will be printed for SPRING Forecast Group.